

# 1976-86 Jeep CJ Tilt Dash Mount Installation Instructions

For Part #'s 2312600051

The original 1976-86 Jeep CJ Series vehicles had two different mounting systems for holding the steering column to the dash. If your Jeep originally had a straight column (non-tilt) you will use your OE mount. If you originally had a tilt steering column, you will need this bracket to mount the ididit column in place of the original.

## Installation:

First, bolt the bracket to the dash using the original bolts. Put the bolts through the holes marked "A" in the bracket.

Second, place the column in the bracket and using the 5/16-18 bolts and washers provided, attach the steering column to the bracket using the "B" mount locations.



ididit inc. 610 S. Maumee St. 49286 Tecumseh, MI • PH: 517-424-0577 • FAX: 517-424-7293 • ididitinc.com

Instruction #: 8000010270 REV 12/12