


Outside Door Handle Flap repair Spring 1968-1982 Corvettes

While holding the handle flap in the fully down position, take the ends of the handle spring ends into the handle.

Push the door handle spring #1014834 at the bend downward until it bottoms over the old spring.

Release the handle flap and the spring is installed.

Lubricate spring every 60 days or when there is no visual sign of oil around the spring. This product carries a 90-day warranty from date of retail purchase.



Bend only in direction shown.

